

INSTRUCTION MANUAL

INSTRUCTIONS FOR DATA LOGGING

TRYSTAR'S M850 DIGITAL METER

INSTRUCTIONS FOR DATA LOGGING

INSTALL DRIVERS ON DATA LOGGING PC


- Drivers for the RS485 to USB connection are required to communicate with the meter
- Some versions of the meter have the CD included with the Installation Manual Packet. CD will have the B&B Electronics Logo — USB Serial Driver v.2.8.29.0. If a CD is not included, please go to

http://www.easysync-ltd.com/product-downloads and download the "USB to RS485" driver.

GO TO TRYSTAR WEBSITE FOR THE MULTILOG SOFTWARE

https://www.trystar.com


01



GO TO BOTTOM OF PAGE AND CLICK ON RESOURCE CENTER




CLICK ON SOFTWARE AND DRIVERS





03

CLICK ON MULTILOG LOGGING SOFTWARE



GO TO COMPUTER DOWNLOAD FILE



RIGHT CLICK ON MULTILOG



CLICK ON RUN AS ADMINISTRATOR




© 2025 All rights reserved.

INSTALLING SOFTWARE


- Click <u>YES</u> to allow program to make changes to computer
- After installation go to Microsoft Start Button and Open MULTILOG software
- Important: Next you must right click on Multilog icon, then right click on Multilog to select "Run as Administrator."
- Once the Multilog opens you must select Settings tab, then Communication tab to access Port Settings. Port Settings must match your computer USB port connected to the power meter. Settings will not necessarily match what is displayed on the next page. To identify your computer's port settings, go to Control Panel, select Device Manager then Ports.

PROJECT SETTINGS


05



PORT SETTINGS




ONCE CONNECTED, YOU SHOULD HAVE THE FOLLOWING




GRAPH SETTINGS

- Right click, select Graph Settings to access the graph preferences. The next page shows typical "Real Time" settings to display available load test data. This screen settings are user friendly and can be changed to opera tor preference.
- The time base unit is the total length of the X axis. I.E. to see one hour in 1 second log intervals, enter 3600.
- The X divisor is the Graph display interval (not the log ging interval). If X = 20, a point will display every 20 log intervals.
- Double click any graph to maximize it on the screen.




DATA LOGGING

- Right click on screen to pull up menu
- Click on Start Data retrieval
- Click on Enable Logging




SCREEN SHOULD INDICATE LOGGING STARTED




END DATA LOGGING

- Click on Stop Data Retrieval
- Click Yes



EXPORT DATA TO CSV FILE

09



SAVE FILE AS CSV



OPEN FILE

